






Spare parts
e·motion

M10/12

4-11




Components






Drive wheel 24"






Battery-pack






Accessories




- 07 05 1324
Spoke guard 24", "Swing" décor
- 07 05 1322
Spoke guard 22", "Swing" décor
- 07 07 1201
Attachment nipple spoke guard



- Tilt supports for e-motion left/right
- 07 05 1110 (narrow version, 12 mm)
- 07 05 1111 (wide version, 15 mm)




Wheel holding device






Battery charger






Remote control

07 05 1022
Remote control EU version (replacement)



07 07 0435
Battery for remote control 12V





Tilt supports

